



The following is a non-comprehensive list of items suggested for installing the LodeArm3030L. It is the installer's responsibility to understand the installation process and tools required prior to performing the work.

WRENCHES AND SOCKETS:	C-CLAMPS	LAYOUT PRINT & TAPE MEASURE
3/8 HEX	MACHINIST LEVEL & BUBBLE LEVEL	CHALK TO MARK PEDESTAL LOCATION
1/2 HEX	HAMMER DRILL	BANDING SHEAR FOR PALLET DISASSEMBLY
11/16 HEX	5/8 CONCRETE BIT	FISH TAPE FOR ROUTING HOSES
13/16 HEX	DRILL	3/4-10 EYE BOLTS FOR LIFTING PEDESTAL
7/8 HEX	Ø .266 DRILL BIT FOR ROTATION STOP	ALIGNMENT BOLTS TO HELP ALIGN LA ONTO PEDESTAL
15/16 HEX	VACUUM TO CLEAR ANCHOR BOLT HOLES	FORKLIFT OR CRANE TO LIFT LA INTO POSITION
1 1/8 HEX	EXTENSION CORDS	PERSONAL PROTECTIVE EQUIPMENT
1 1/2 HEX (QTY 2) WRENCH	SLINGS	SAW FOR PALLET DISASSEMBLY
3/16 ALLEN HEX	LADDERS	
5/16 ALLEN HEX	MAN LIFT	
3/8 ALLEN HEX	PLUMBING TOOLS	
5/8 ALLEN HEX	ELECTRICAL TOOLS	
TORQUE WRENCH		

ALL DESIGNS, SKETCHES AND DRAWINGS ARE THE PROPERTY OF POSITECH CORPORATION LETTING, OR ALLOWING TO BE LET, THE KNOWLEDGE FOR DESIGN AND/OR FABRICATION FROM SAID DESIGNS, SKETCHES OR DRAWINGS WITHOUT THE WRITTEN CONSENT OF POSITECH CORPORATION IS EXPRESSLY FORBIDDEN.



LodeArm 3030L			
SCALE: 1:24	DATE: 5/20/2014	DRAWN BY: KPS	
CLASS CODE: 920	DWG NO: LA3030L INSTALL	SHT: 1 of 1	REV: