



The following is a non-comprehensive list of items suggested for installing the LodeArm3030L. It is the installer's responsibility to understand the installation process and tools required prior to performing the work.

WRENCHES AND SOCKETS:	C-CLAMPS	LAYOUT PRINT & TAPE MEASURE
M20 HEX	MACHINIST LEVEL & BUBBLE LEVEL	CHALK TO MARK PEDESTAL LOCATION
1 1/2" HEX	HAMMER DRILL	BANDING SHEAR FOR PALLET DISASSEMBLY
2 1/4" HEX WRENCH	1" CONCRETE BIT	FISH TAPE FOR ROUTING HOSES
3" HEX WRENCH	DRILL	3/4-10 EYE BOLTS FOR LIFTING PEDESTAL
9/16 ALLEN HEX	VACUUM TO CLEAR ANCHOR BOLT HOLES	ALIGNMENT BOLTS TO HELP ALIGN WM ONTO PEDESTAL
5/8 ALLEN HEX	EXTENSION CORDS	FORKLIFT OR CRANE TO LIFT WM INTO POSITION
M8 ALLEN HEX	SLINGS	PERSONAL PROTECTIVE EQUIPMENT
M14 ALLEN HEX	LADDERS	SAW FOR PALLET DISASSEMBLY
TORQUE WRENCH	MAN LIFT	
	PLUMBING TOOLS	
	ELECTRICAL TOOLS	

ALL DESIGNS, SKETCHES AND DRAWINGS ARE THE PROPERTY OF POSITECH CORPORATION LETTING, OR ALLOWING TO BE LET, THE KNOWLEDGE FOR DESIGN AND/OR FABRICATION FROM SAID DESIGNS, SKETCHES OR DRAWINGS WITHOUT THE WRITTEN CONSENT OF POSITECH CORPORATION IS EXPRESSLY FORBIDDEN.



WM 200		
SCALE: 1:18	DATE: 10/Nov/2015	DRAWN BY: KWO
DWG: NO: WM INSTALLATION		SHT: 1 of 1 REV: