



The following is a non-comprehensive list of items suggested for installing the LodeArm. It is the installer's responsibility to understand the installation process and tools required prior to performing the work.

| WRENCHES AND SOCKETS: | TORQUE WRENCH | LAYOUT PRINT & TAPE MEASURE |
|--------------------------|-----------------------------------|--|
| 3/8 HEX | C-CLAMPS | CHALK TO MARK PEDESTAL LOCATION |
| 1/2 HEX | MACHINIST LEVEL & BUBBLE LEVEL | BANDING SHEAR FOR PALLET DISASSEMBLY |
| 1 1/4 HEX / OPEN WRENCH | HAMMER DRILL | FISH TAPE FOR ROUTING HOSES |
| 1 3/8 HEX | 1" CONCRETE BIT | 1-8 EYE BOLTS FOR LIFTING PEDESTAL |
| 1 1/2 HEX (QTY 2) WRENCH | DRILL | ALIGNMENT BOLTS TO HELP ALIGN LA ONTO PEDESTAL |
| 2 1/4 HEX | Ø.266 DRILL BIT FOR ROTATION STOP | FORKLIFT OR CRANE TO LIFT LA INTO POSITION |
| 3 HEX | VACUUM TO CLEAR ANCHOR BOLT HOLES | PERSONAL PROTECTIVE EQUIPMENT |
| 3/16 ALLEN HEX | EXTENSION CORDS | SAW FOR PALLET DISASSEMBLY |
| 1/4 ALLEN HEX | SLINGS | PLUMBING TOOLS |
| 5/16 ALLEN HEX | LADDERS | ELECTRICAL TOOLS |
| 3/8 ALLEN HEX | MAN LIFT | |
| 5/8 ALLEN HEX | | |
| 3/4 ALLEN HEX | | |

ALL DESIGNS, SKETCHES AND DRAWINGS ARE THE PROPERTY OF POSITECH CORPORATION LETTING, OR ALLOWING TO BE LET, THE KNOWLEDGE FOR DESIGN AND/OR FABRICATION FROM SAID DESIGNS, SKETCHES OR DRAWINGS WITHOUT THE WRITTEN CONSENT OF POSITECH CORPORATION IS EXPRESSLY FORBIDDEN.

Positech CORPORATION

LODEARM® 3030LE

| | | |
|-----------------|--------------------------|---------------|
| SCALE: 1:24 | DATE: Nov-30-2015 | DRAWN BY: kps |
| CLASS CODE: 920 | DWG NO: LA3030LE INSTALL | SHT: 1 of 1 |
| | | REV: |