



The following is a non-comprehensive list of items suggested for installing the ReactionArm 6000. It is the installer's responsibility to understand the installation process and tools required prior to performing the work.

WRENCHES AND SOCKETS:	C-CLAMPS	LAYOUT PRINT & TAPE MEASURE
3/8" HEX	MACHINIST LEVEL & BUBBLE LEVEL	CHALK TO MARK PEDESTAL LOCATION
7/16" HEX	HAMMER DRILL	BANDING SHEAR FOR PALLET DISASSEMBLY
1/2" HEX	1" CONCRETE BIT	FISH TAPE FOR ROUTING HOSES
3/4" HEX	DRILL	EYE BOLTS FOR LIFTING PEDESTAL
1 1/2" HEX (QTY 2) WRENCH	0.266 DRILL BIT FOR ROTATION STOP	SLINGS
2 1/4" HEX	VACUUM TO CLEAR ANCHOR BOLT HOLES	ALIGNMENT BOLTS TO HELP ALIGN RA ONTO PEDESTAL
3" HEX	EXTENSION CORDS	FORKLIFT OR CRANE TO LIFT RA INTO POSITION
3/8" ALLEN HEX	LADDERS	PERSONAL PROTECTIVE EQUIPMENT
5/8" ALLEN HEX	MAN LIFT	
3/4" ALLEN	PLUMBING TOOLS	
TORQUE WRENCH	ELECTRICAL TOOLS	

ALL DESIGNS, SKETCHES AND DRAWINGS ARE THE PROPERTY OF POSITECH CORPORATION LETTING, OR ALLOWING TO BE LET, THE KNOWLEDGE FOR DESIGN AND/OR FABRICATION FROM SAID DESIGNS, SKETCHES OR DRAWINGS WITHOUT THE WRITTEN CONSENT OF POSITECH CORPORATION IS EXPRESSLY FORBIDDEN.



LODEARM® 4500H			
SCALE: 1:24	DATE: Aug-12-2015	DRAWN BY: KPS	
CLASS CODE: 985	DWG NO: LA4500H	SHT: 1 of 1	REV: