



The following is a non-comprehensive list of items suggested for installing the LodeArm4500L. It is the installer's responsibility to understand the installation process and tools required prior to performing the work.

WRENCHES AND SOCKETS:	C-CLAMPS	LAYOUT PRINT & TAPE MEASURE
3/8 HEX	MACHINIST LEVEL & BUBBLE LEVEL	CHALK TO MARK PEDESTAL LOCATION
1/2 HEX	HAMMER DRILL	BANDING SHEAR FOR PALLET DISASSEMBLY
11/16 HEX	5/8 CONCRETE BIT	FISH TAPE FOR ROUTING HOSES
13/16 HEX	DRILL	3/4-10 EYE BOLTS FOR LIFTING PEDESTAL
7/8 HEX	Ø.266 DRILL BIT FOR ROTATION STOP	ALIGNMENT BOLTS TO HELP ALIGN LA ONTO PEDESTAL
15/16 HEX	VACUUM TO CLEAR ANCHOR BOLT HOLES	PEDESTAL
1 1/8 HEX	EXTENSION CORDS	FORKLIFT OR CRANE TO LIFT LA INTO POSITION
1 1/2 HEX (QTY 2) WRENCH	SLINGS	PERSONAL PROTECTIVE EQUIPMENT
3/16 ALLEN HEX	LADDERS	SAW FOR PALLET DISASSEMBLY
5/16 ALLEN HEX	MAN LIFT	
3/8 ALLEN HEX	PLUMBING TOOLS	
5/8 ALLEN HEX	ELECTRICAL TOOLS	
TORQUE WRENCH		

ALL DESIGNS, SKETCHES AND DRAWINGS ARE THE PROPERTY OF POSITECH CORPORATION LETTING, OR ALLOWING TO BE LET, THE KNOWLEDGE FOR DESIGN AND/OR FABRICATION FROM SAID DESIGNS, SKETCHES OR DRAWINGS WITHOUT THE WRITTEN CONSENT OF POSITECH CORPORATION IS EXPRESSLY FORBIDDEN.

		LODEARM® 4500L	
		SCALE: 1:24	DATE: May-20-2014
CLASS CODE: 920	DWG NO: LA4500L INSTALL	DRAWN BY: KPS	REV:
		SHT: 1 of 1	