



The following is a non-comprehensive list of items suggested for installing the LodeArm II. It is the installer's responsibility to understand the installation process and tools required prior to performing the work.

WRENCHES AND SOCKETS:		
3/8 HEX	C-CLAMPS	BANDING SHEAR FOR PALLET DISASSEMBLY
1/2 HEX	MACHINIST LEVEL & BUBBLE LEVEL	LAYOUT PRINT & TAPE MEASURE
9/16 HEX	HAMMER DRILL	FISH TAPE FOR ROUTING HOSES
11/16 HEX	5/8 CONCRETE BIT	PERSONAL PROTECTIVE EQUIPMENT
15/16 HEX (QTY 2)	DRILL	FORKLIFT OR CRANE TO LIFT LA INTO POSITION
1 1/2 HEX (QTY 2) WRENCH	Ø .266 DRILL BIT FOR ROTATION STOP	SAW FOR PALLET DISASSEMBLY
3/16 ALLEN HEX	VACUUM TO CLEAR ANCHOR BOLT HOLES	PLUMBING TOOLS
5/16 ALLEN HEX	EXTENSION CORDS	ELECTRICAL TOOLS
3/8 ALLEN HEX	LADDERS	SLINGS
5/8 ALLEN HEX	MAN LIFT	
TORQUE WRENCH	FLAT HEAD SCREW DRIVER	

ALL DESIGNS, SKETCHES AND DRAWINGS ARE THE PROPERTY OF POSITECH CORPORATION LETTING, OR ALLOWING TO BE LET, THE KNOWLEDGE FOR DESIGN AND/OR FABRICATION FROM SAID DESIGNS, SKETCHES OR DRAWINGS WITHOUT THE WRITTEN CONSENT OF POSITECH CORPORATION IS EXPRESSLY FORBIDDEN.

		LODEARM® II	
SCALE: 1:10	DATE: Jan-29-2016	DRAWN BY: KPS	
CLASS CODE: 985	DWG NO: LA II INSTALL	SHT: 1 of 1	REV: